




tolltickets Camper Box







The tolltickets Camper Box is a dedicated toll solution for camper vans and buses above 3.5 t.

It enables seamless toll payment across multiple European networks.







One device. One contract. Multiple destinations.

Account and service features:

-  Online customer account
-  Device blocking in case of loss or theft
-  Vehicle change possible
-  Subscription termination available
-  Multilingual platform: EN, DE, FR, IT, ES, NL, PL
-  Support at: tolltickets.com/contact



The Camper Box covers the following countries:

	France
	Italy
	Spain
	Portugal
	Austria
	Norway
	Øresund Bridge Storebælt Bridge Liefkenshoektunnel Herrentunnel Warnowquerung

Commercial conditions:

Yearly rental fee:

€89.90 incl. VAT

Activation fee:

€19.90


Toll surcharge:

5% on gross toll turnover



User and Installation Guide

TOLLTICKETS



1) INSTALLATION ON THE WINDSHIELD

1. Clean and dry the inner windshield surface.
2. Remove the protective film from the adhesive pad.
3. Position the unit on the inside of the windshield (at the bottom center) and press firmly for a few seconds.
4. Do not mount the unit outside the vehicle.

Choose a position that does not obstruct the driver's view.


For vehicles with heated windshields or insulating glass, the toll box signal may be interrupted.

2) POWER CONNECTION (REQUIRED)

The device must always be plugged into a power source. There are two ways to do this:

- **Option A:** Plug-and-Play with the cigarette lighter socket (use the supplied cable).
- **Option B:** Hardwiring (recommended to be carried out at a qualified workshop).

Without external power, a fully charged device operates about 2 to 3 hours. Keep the device connected to power to avoid going offline.




3) INITIAL START-UP

1. Select the device language.
2. Confirm the vehicle license plate number shown on screen.
3. **Do not change the trailer weight and axles number which must be set to zero!**

4) BEFORE EACH TRIP

1. Check that the license plate number is correct.
2. Check that your device is working properly (Green LED is displayed after a few minutes when driving).



5) DISPLAY AND ICONS

- Do not interact with the unit while passing through an automated toll lane.
- Only use the buttons while the vehicle is stopped (buttons are disabled above 10 km/h).
- Icons indicate: mobile signal, battery level, new message, and external power connected.
- If the vehicle is stationary for more than 15 minutes, the device enters parking mode (display and LEDs off).


6) BEEPS AND LEDS

- OK state: 1 medium beep, green LEDs. Driving allowed.
- Warning state: 2 long beeps, flashing green LEDs. Check the message.
- Error state (contractual/technical/fatal): 4 short beeps, red LEDs. Driving in the toll domain is not allowed until resolved.


If an error persists, contact tolltickets support.



OK



WARNING



ERROR